

HPA 3 Power Amplifier

# WARNING: TO REDUCETHERISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE



CAUTION: TO REDUCE THE RISK OF ELECTRICAL SHOCK, DO NOT REMOVE COVER. NO USER-SERVICEABLE PARTS INSIDE REFER SERVICING TO QUALIFIED PERSONNEL.



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.



Marking by the "CE" symbol (shown left) indicates compliance of this device with the EMC (Electromagnetic Compatibility) and LVD (Low Voltage Directive) standards of the European Community.

The information contained in the manual is subject to change without notice. The most current version of this manual will be posted on our web site at http://www.madrigal.com.

# Important Safety Instructions

Please read all instructions and precautions carefully and completely before operating your Proceed power amplifier.

- 1. **ALWAYS** disconnect your entire system from the AC mains before connecting or disconnecting any cables, or when cleaning any component.
- 2. This product is equipped with a three-conductor AC mains power cord which includes an earth ground connection. To prevent shock hazard, all three connections must ALWAYS be used. If your electrical outlets will not accept this type of plug, an adapter may be purchased. If an adapter is necessary, be sure it is an approved type and is used properly, supplying an earth ground. If you are not sure of the integrity of your home electrical system, contact a licensed electrician for assistance.
- AC extension cords are not recommended for use with this product. If an extension cord must be
  used, be sure it is an approved type and has sufficient current-carrying capacity to power this
  product.
- 4. NEVER use flammable or combustible chemicals for cleaning audio components.
- 5. NEVER operate this product with any covers removed.
- 6. NEVER wet the inside of this product with any liquid.
- 7. NEVER pour or spill liquids directly onto this unit.
- 8. NEVER block air flow through ventilation slots or heatsinks.
- 9. NEVER bypass any fuse.
- 10. NEVER replace any fuse with a value or type other than those specified.
- 11. NEVER attempt to repair this product. If a problem occurs, contact your Proceed® retailer.
- 12. **NEVER** expose this product to extremely high or low temperatures.
- 13. NEVER operate this product in an explosive atmosphere.
- 14. ALWAYS keep electrical equipment out of the reach of children.
- 15. ALWAYS unplug sensitive electronic equipment during lightning storms.

From all of us at Madrigal Audio Laboratories, thank you for choosing this Proceed power amplifier.  Agreat deal of effort went into the design and construction of this precision device. Used properly, it will give you many years of enjoyment.

# Table of Contents

Unpacking and Placement	6
Unpacking	
Plac em ent	
Ventilation	_
Operating Voltage	_
Note the serial number	
amp lifier b ottom-panel label	
A Quick Start	
Special Design Features	
Tiple monaural design	
Low impedance power supply	
Balanced inputs	
Robust output stage	
Extensive protection	
Front Panel	
Rear Panel	
communication cable	
Remote turn-on tip polarity	
Bridged Operation	
Bridging Explained	
Balanced Bridging	
Balanced Bridging Kit	
Single-Ended Bridging	
Single-Ended Bridging Kit	
Biamplification	
Balanced Yadapter	
Care & Maintenance	
U.S. and Canadian Warranty	
90-Day Limited Warranty	
Five Year Extended Warranty	
Obtaining Service	
Specifications	
Dimensions	
Rack Mounting	
Installation Notes	
Installation Notes	

# Unpacking and Placement

### Unpacking

Unpack your Proceed® HPA 3 Power Amplifier and keep all packing materials for future transport. Shipment of the amplifier without the original packing material is not recommended, as it is heavy enough to make improvised packaging impractical. Locate and remove all accessory items from the cartons, and store the cartons for possible future use.

Carefully inspect the product for shipping damage. If you discover any, see your Proceed dealer immediately.

### Placement

Your Proceed amplifier may be placed either near the preamplifier/control center or near the loudspeakers. It may be placed on a shelf or in a cabinet where it is convenient to operate.

Note that adequate clearance for the AC cord and connecting cables must be left behind your amplifier. We suggest leaving at least three inches of free space behind your amplifier to allow all cables sufficient room to bend without crimping or undue strain.

### Ventilation

Be sure to allow at least 2 to 3 inches of clearance above your amplifier to allow heat dissipation through air circulation. The vents on both the bottom and the top of the amplifier must be kept free from any obstruction which would reduce the flow of air through the unit. The best rule of thumb is this: if the top of your amplifier is too hot to touch when "idle," it needs better ventilation. If so, consider drilling holes in the supporting shelf under the amplifier to promote flow-through ventilation, or use fans to increase air circulation.

Open equipment racks are generally best for power amplifiers, as they allow ample ventilation. If your amplifier must be located inside a cabinet which restricts airflow, consider using some fans to increase ventilation.

Avoid placement on soft surfaces such as carpeting. If you prefer to have the amplifier on the floor near your loudspeakers, be sure to place it on a firm surface. (A thick piece of tempered glass under the amplifier is aesthetically unobtrusive while providing firm support and allowing the required ventilation.)

Mechanical drawings are included in this manual to facilitate special installations and custom cabinet work (see 'Dimensions' at the end of this manual).

### **PRECAUTION**

For your protection, review "Important Safety Instructions" before you install your amplifier.

# Operating Voltage

This Proceed amplifier is factory-set for 100 V, 120 V, 220 V or 240 V AC mains operation at either 50 or 60 Hz, according to the country for which the unit was manufactured. (230 V in European Union countries, in compliance with CE regulations.) Make sure that the label on the rear panel of the amplifier indicates the correct AC operating voltage for your location. The operating voltage cannot be changed by the user, and any attempt to do so will void the warranty.

If the voltage indicated does not match the service in your area, see your Proceed dealer

Note the serial number

While you are checking the voltage, it would probably be a good idea to make a record of the serial number for your amplifier. This can be found on the label found on the bottom of the amplifier.

amplifier bottom-panel label



# A Quick Start

We recognize that many people are understandably eager to begin listening to their new components, and that reading the manual is often done (if at all) at a later time—perhaps while listening to music through the new product itself We strongly recommend that you read this manual thoroughly.

Fortunately, we can help you get some music up and running on your system quickly, so that you may begin enjoying your new amplifier while reading more about it. The goal here is simply to make some music as quickly as possible.

The following procedure assumes that the rest of your system is already connected (e.g., source components to preamplifier).

### 1 TURN DOWN THE VOLUME ON YOUR PREAMPLIFIER

Turning the volume on the preamp all the way down minimizes the opportunity for unpleasant surprises when first powering up your new amplifier. It does not need to be turned off—merely turned down.

### 2 SELECT" XLR" OR "RCA" WITH THE "INPUT SELECT" SWITCHES

Each channel of the Proceed HPA 3 Power Amplifier has both balanced (XLR) and single-ended (RCA) inputs, with a small switch between the two connectors to select between them. Using these switches, select the appropriate input for each channel, given your interconnecting cables and preamplifier/controller's capabilities.

### 3 CONNECTYOUR PREAMP TO THE AMPLIFIER

Having selected the appropriate inputs in Step 2, now connect the outputs of your preamplifier to the corresponding inputs on the power amplifier

### 4 CONNECTYOUR SPEAKERS TO THE AMPLIFIER

Connect speaker wire from the amplifier to your loudspeakers. Be sure to maintain consistency in polarity, e.g., the red post on the amplifier to the red connector on the speaker, and likewise black to black. (Getting the wires mixed up won't damage anything, but the sound will be lacking in bass and the imaging will be quite poor and unstable.)

### 5 CONNECT THE AC CORD TO THE AMPLIFIER AND TO YOUR AC OUTLET

The AC receptacle for the power cord is located on the right side of the rear panel, as seen from the front.

### 6 TURN ON THE AMPLIFIER BY PRESSING POWER, THEN STANDBY

Press the latching **power** button on the front panel of the amplifier (small, near the bottom) to connect the amplifier to the AC mains. The amplifier will initially power up in standby mode. After five seconds (to let the power supply charge up), pressing the large silver **standby** button will bring the amplifier out of standby into its normal, fully operational mode.



Congratulations! You should now be able to enjoy your favorite music while reading the rest of this manual. (Please, do read the rest of this manual. It contains much valuable information about your new amplifier which we could not possibly fit onto these two pages.)

# Special Design Features

Congratulations on your purchase of a Proceed amplifier! While your new amplifier is straightforward in its use, it includes several design features which are responsible for its outstanding performance. A few of these are given below.

### Triple monaural design

Consistent with the finest amplifiers, each audio channel of your Proceed HPA 3 has its own, dedicated power supply—including a separate 663 VA toroidal transformer for each channel. The resulting reduction in crosstalk between audio channels provides superior imaging and reproduction of acoustic space. Demands placed on one channel have virtually no effect on the performance of the other channel.

### Low impedance power supply

A critical factor in the ultimate performance of an amplifier is its "power supply impedance," which can be loosely thought of as the freedom with which the audio circuitry has access to the power it needs, when it needs it The design of your Proceed amplifier has addressed this important characteristic in a comprehensive fashion. For example, the power supply capacitors (which act as "feservoirs" of power for the amplifier circuitry) are mounted directly to the printed circuit board rather than using point to point wiring. The layout of the circuitry uses short, thick traces for high current paths. This attention to detail yields an optimal environment in which the amplifier may operate to its maximum potential.

### Balanced inputs


Each channel of your amplifier is individually configurable to receive either balanced or single-ended inputs. This approach allows you to take full advantage of the greater immunity from noise, RFI, and EMI which balanced transmission of audio signals offers on any preampto-amplifier connection where it is supported. At the same time, any or all channels of the amplifier may be configured for single-ended inputs to maintain compatibility with the majority of preamplifiers available today. The gain structure of the amplifier adjusts automatically when you select different inputs to facilitate this "mix and match" approach.

### Robust output stage

Each channel of your Proceed amplifier uses twelve 150 watt power transistors. These transistors are all individually tested and sorted, and are used in matched sets to ensure that no one transistor bears a disproportionate part of the overall load. The combination of an "overbuilt" design specification and extraordinary attention to detail in manufacturing improves performance, reliability, and longevity.

### Extensive protection

Your Proceed amplifier will shut itself down if it senses either the presence of either DC (direct current) or a short circuit at the output, or any unsafe operating temperature. In any case, a power relay will cause the amplifier to be disconnected from the AC mains. In addition, the AC input to each transformer is fused to protect against any possibility of component-level failure that could draw dangerous amounts of power Finally, inrush limiting prevents premature aging of power supply components during power-up. Once the power supply has been charged, this in-rush limiting circuitry effectively defeats itself to allow unfettered power supply access to the AC mains.



# Front Panel

### 1 POWER BUTTON

Pressing this latching **power** button connects the amplifier to the AC mains, charges the power supply (which takes about five seconds), and places it in standby. Having a true standby function keeps the sensitive voltage gain stages warmed up and sounding their best at all times. Power consumption when in standby is less than 125 watts.

Note that if the amplifier has been disconnected from the AC mains power by depressing the front panel **power** button or by unplugging it from the AC outlet, it cannot respond to a remote turn-on command from a control unit If you wish the amplifier to turn on and off via the Proceed communications bus (or by a DC trigger), the amplifier needs to be in standby, with this **power** button engaged.

### 2 STANDBY BUTTON

Assuming that the power is on and the unit is in standby (see 1, above), pressing the **standby** button engages the output stage of the amplifier, taking it from **standby** to fully **on**. Pressing the **standby** button again will toggle the amplifier back to standby. Power consumption when fully on and at idle is less than 200 watts.

At your option, you may also toggle the amplifier between **standby** mode and fully **on** by connecting a suitable 5-12V DC trigger such as can be provided by the Proceed PDSD or AVP to its **remote trigger input**.


Note that pressing the **standby** button has no effect until after the power supply is fully charged.

Note also that if the amplifier has been disconnected from the AC mains power by depressing the front panel **power** button, it cannot respond to a remote turn-on command from a control unit

### 3 INDICATOR LIGHTS

The power indicator light (above the small power button, below the large standby button) is normally either on or off, indicating whether AC power is being supplied to the amplifier. It will blink on and off if the amplifier's protection circuitry has been engaged (shutting the amp off to protect itself and/or your loudspeakers). In the unlikely event that you see the power indicator blinking, disconnect the amplifier from AC power and call your dealer for assistance in solving the problem.

The **standby indicator light** (above the large **standby** button) glows either amber or red, depending on the operational status of your amplifier Amber indicates that the amplifier is **on** and ready to be used. When the indicator light is glowing red, the unit is in **standby**. If the standby indicator light is completely off, the amplifier is not receiving power. Check your AC connections and the rear-panel AC fuse.



# Rear Panel



Caution!

Turn the volume on your controller/preamplifier all the way down before attempting to connect anything to your Proceed HPA 3 Power Amplifier.

### 1 AC MAINS RECEPTACLE

Connect the AC power cord (included in the accessory pack) to the IEC-standard AC receptacle on the rear panel of the amplifier, then to the AC mains outlet.



Warning!

Your Proceed amplifier has been safety-tested and is designed for operation with a three-conductor power cord. Do not defeat the "third pin" or earth ground of the AC power cord.

### 2 COMMUNICATION PORTS

These RJ-45 communications ports provide for sophisticated inter-component communications within the context of a Proceed system, allowing the multichannel controller to toggle the amplifier between **operate** and **standby** as needed, without forcing the user to turn the amplifier on separately. Since this communication link provides two-way communication, it is more reliable and preferred over simpler DC trigger hookups (although we support DC triggers as well, since their use is so widespread).

These two RJ-45 communications ports also support the PHAST<sup>TM</sup> intercomponent communications protocols, greatly simplifying the design and installation of sophisticated home automation systems. They provide two-way communication with the home automation controller as to the amplifier's current status, ensuring reliable execution of sophisticated turnon and shutdown macros.

To use these ports, simply daisy chain the various Proceed products together. The modular cable needed for the connection may be purchased from your Proceed dealer. It may also be easily and inexpensively made to length using two modular connectors and the appropriate length (up to 100 feet/30 meters) of flat, eight conductor cable.

Modular cables and connectors are used throughout the world for both telecommunications and computers, and are widely available at low cost. The connectors are crimped on to the ends of the cable such that pin 1 at one end is connected to pin 1 at the other end. Such a "straight-through" connection is (counter-intuitively) made by introducing a 180° twist in the cable between the two ends, as shown below.

### communication cable



## 3 REMOTE TURN-ON ("TRIGGER") JACKS

Two 1/8" "mini" jacks above the AC mains receptacle on the rear panel allows remote-controlled turn-on (that is, toggling between operate and standby) of the Proceed amplifier. These remote "triggers" will be operated by the presence of 5–12 volts DC, with tip polarity as shown below:

### Remote turn-on tip polarity



The presence of a suitable DC voltage will cause the amplifier to be fully on; the absence of such a voltage will cause it to enter standby. Your Proceed dealer can help you take advantage of these design features to maximize your system's versatility.

Since these trigger inputs are wired in parallel, you can go into one and out of the other to facilitate a 'daisy-chain' of turn-on triggers (should you have additional products that need to be controlled in this manner).

Note:

If the DC trigger input is used to control the amplifier(s), the last mini-jack in the chain must be filled with a dummy  $\frac{1}{2}$ " plug [that is, an empty plug must be inserted into the final  $\frac{1}{2}$ " [3.5 mm] jack]. Even if only a single amplifier is controlled in this fashion, the "extra" mini-jack must be filled with a dummy plug.

If you are not using these turn-on inputs, you may leave them both empty of any plugs.

### 4 BALANCED AUDIO INPUTS

Accepts signals from preamplifiers with balanced outputs via high quality XIR connectors.

The pin assignments of these XLR-type female input connectors are:



Pin 1: Signal ground

Pin 2: Signal + (non-inverting)

Pin 3: Signal - (inverting)

Connector ground lug: chassis ground

These pin assignments are consistent with the standards adopted by the Audio Engineering Society. Refer to the operating manual of your balanced-output preamplifier to verify that the pin assignments of its output connectors correspond to your Proceed amplifier If not, wire the cables so that the appropriate output pin connects to the equivalent input pin.

If you are planning to use balanced connections between your preamplifier and any particular channel of the amplifier, select the balanced input by sliding the **input select switch** (see Item 5, below) toward the XIR input. Then connect the balanced outputs of your preamplifier to the corresponding balanced inputs on the amplifier using high quality cables such as CZ Gel-1.

### 5 INPUTSELECTSWITCH

This small switch is found between the balanced XIR input and the single-ended RCA input on each channel of the amplifier. Use it to select which of the two inputs you plan to use.

The input select switch disables the unselected input in order to avoid any pickup of stray noise from what would otherwise be an open input. It also causes the effective gain of that channel to be adjusted (either 23 dB balanced or 29 dB single-ended, to compensate for the 6 dB difference in signal level in these two connection standards). Should you use your amplifier in a home theater system, this adjustment allows you to use any combination of balanced and single-ended connections without having to worry about going outside the adjustment range of your surround decoder's output calibration circuitry.

### 6 SINGLE-BNDED INPUTS

Accepts signals from preamp/controllers with single-ended outputs via high quality RCA connectors.

If you are planning to use single-ended connections between your preamplifier and any particular channel of the amplifier, select the single-ended input by sliding the **input select switch** (see Item 5) toward the RCA input. Then connect the single-ended outputs of your preamplifier to the corresponding single-ended inputs on the amplifier, using high quality cable such as CZ Gel-2.

### 7 SPEAKER OUTPUTS & BINDING POSTS

This Proceed amplifier is equipped with gold-plated, high-current binding posts for output termination to a loudspeaker system. To take full advantage of the amplifier's sonic quality, we recommend using high-quality speaker cable; see your Proceed dealer.



Caution!

NEVER connect the amplifier output terminals to any device other than a loudspeaker.

NEVER short-circuit the amplifier's output terminals.

There are two recommended methods for connecting speaker cables to the amplifier A high-quality spade lug or hook lug, soldered to the cable (or crimped with extremely high pressure), is best.







Hooklug

For each channel in turn, connect the left-channel — (negative or black) output post of the amplifier to the — (negative or black) input terminal of the appropriate loudspeaker

Then connect the + (positive or red) output post of the amplifier to the + (positive or red) input terminal of the appropriate loudspeaker.

Repeat this procedure for the other channels.

# **Bridged Operation**

Your Proceed amplifier has been designed to be extremely versatile. Should your needs change or grow over time, you may wish to add additional power by one of two means: Bridging, or Biamping. We will discuss bridged operation first.

### Bridging Explained

Bridging refers to the act of reconfiguring the circuitry in two channels of your amplifier to act as though it were a single, much larger amplifier (Of course, this reduces the number of available channels; you may need more amplifiers to make up the difference.)


Bridging is accomplished by sending a normal signal to one channel and an *inverted* signal to the other. In this configuration, one channel will always be "pushing" when the other is "pulling." By connecting the loudspeaker leads across the left and right red output terminals, the amplifier can now deliver twice the normal voltage to the loudspeaker. Working together this way, the two amplifier channels can deliver about *four times* the power to a speaker that a single channel could deliver on its own.

Bridged operation is particularly beneficial with low sensitivity, high-impedance loudspeakers (8 $\Omega$  or higher) that have a greater need for voltage than for current. It is not recommended for low-impedance loudspeakers, as the speaker's impedance is "split" by the two halves of the amplifier. Thus the bridged amplifier "sees" a  $2\Omega$  load when connected to a  $4\Omega$  loudspeaker. Delivery of high power into such a low impedance creates a great deal of heat that needs to be dissipated. (Of course, your amplifier is protected against overheating, but having an amplifier shut itself down even temporarily can put a damper on the evening's entertainment)

### Balanced Bridging

If your preamplifier has balanced outputs, you should use them. For this discussion, we will assume that you are using a Madrigal Balanced Bridging Kit for each channel to be bridged. (Alternatively, you may have custom cables built using your preferred wire and connectors, being careful to follow the wiring diagram below.)

### Balanced Bridging Kit



Bridging Output Adapter (not drawn to scale)



The "normal" leg of the Madrigal Balanced Bridging Input Adapter will be marked with a red stripe to indicate positive polarity, and the inverted leg will be marked with a black stripe to indicate inverted polarity (corresponding to the red and black terminals of your loudspeaker).

The Balanced Bridging Output Adapter is simply a heavy-gauge copper bar (silver- and gold-plated) used to strap two of the output ground terminals together. This establishes a common reference for the amplifier and completes the circuit that includes the loudspeakers.



Important!

Do not attempt to operate your amplifier in a bridged mode without first strapping the black output terminals together. Failure to establish a common ground reference between the two channels can damage your amplifier by forcing significant currents to flow where they do not belong!

To bridge your amplifier using a balanced input signal, follow these steps:

### 1 DISCONNECTYOUR AMPLIFIER FROM EVERYTHING

Start with your amplifier totally disconnected from inputs, outputs, and AC power. It is always best to power down an amplifier before changing connections; here you are also changing its basic configuration, making this step essential.

### 2 CONNECT THE BALANCED BRIDGING INPUT A DAPTER TO THE INPUTS

Connect the two male XIRs to two adjacent inputs on your amplifier, noting which XIR is marked red and which is black. The channel with the red, normal input will later be connected to the red, positive terminal of your loudspeaker. Don't forget to choose the balanced input on each channel using the switch located between the XIR and the RCA connectors.

# 3 CONNECTTHE BALANCED BRIDGING OUTPUT ADAPTER TO THE TWO BLACK OUTPUT TERMINALS

Connect one end of the Balanced Bridging Output Adapter to a black output terminal on one of the two channels to be bridged together, and then connect the other end of the Output Adapter to a black output terminal on the other channel. Make sure these connections are snug and secure. (If you need to use two channels of a different spacing—for example, two center channel in different amplifiers—you can use a heavy gauge speaker wire for this purpose.)

# 4 CONNECTYOUR LOUDSPEAKER WIRE ACROSS TWO RED OUTPUTTERMINALS, ONE TO EACH OF THE TWO CHANNELS BEING BRIDGED

Please read the following carefully:

Connect the positive/+/red binding post of your loudspeaker to the red output terminal associated with the red (normal) side of the Input Adapter.

Connect the negative/-/black binding post of your loudspeaker to the *red* output terminal on the other side of the amplifier, the one associated with the black (inverted) side of the Input Adapter

Following this connection convention preserves the polarity of the signal sent to the loudspeaker In practice, the most important thing is to be consistent throughout the system, as inconsistency will result in out-of-phase loudspeakers. In turn, this results in unstable imaging and poor bass reproduction. (The effect is not dangerous, but neither is it desirable.)

### 5 CONNECTONE OUTPUT CHANNEL OF YOUR PREAMPLIFIER TO THE IN-PUT OF YOUR BRIDGED AMPLIFIER

The female XLR at the junction of the Balanced Bridging Input Adapter is now the *single* input to this *bridged* pair of amplifier channels.

### 6 POWER UP YOUR AM PLIFIER


Plug the amplifier back into the AC mains; press the **power** button to turn on the amplifier


### 7 REPEATTHIS PROCESS WITH YOUR OTHER AMPLIFIER(S)

### Single-Ended Bridging

If your preamplifier has only single-ended (RCA) outputs, a few details of bridged operation will differ from the discussion above, all pertaining to the connection of the preamp to the bridged amplifiers. For this discussion, we will assume that you are using a Madrigal Single-Ended Bridging Kit for each channel to

be bridged. (Alternatively, you may have custom cables built using your preferred wire and connectors, being careful to follow the wiring diagram below.)





# Bridging Output Adapter (not drawn to scale)



The "normal" leg of the Madrigal Single-Ended Bridging Input Adapter will be marked with a red stripe to indicate positive polarity, and the inverted leg will be marked with a black stripe to indicate inverted polarity (corresponding to the red and black terminals of your loudspeaker).

The Single-Ended Bridging Output Adapter is simply a heavy-gauge copper bar (silver- and gold-plated) used to strap two of the output ground terminals together. This establishes a common reference for the amplifier and completes the circuit that includes the loudspeakers.



Important!

Do not attempt to operate your amplifier in a bridged mode without first strapping the black output terminals together. Failure to establish a common ground reference between the two channels can damage your amplifier by forcing significant currents to flow where they do not belong!

To bridge your Proceed amplifier using a single-ended (RCA) input signal, follow these steps:

### 1 DISCONNECTYOUR AMPLIFIER FROM EVERYTHING

Start with your amplifier totally disconnected from inputs, outputs, and AC power. It is always best to power down an amplifier before changing connections; here you are changing its basic configuration, making it essential.

# 2 CONNECTTHE SINGLE-ENDED BRIDGING INPUTA DAPTER TO THE AMP'S INPUTS

Connect the two male XIRs to two inputs of your amplifier, noting which XIR is marked red and which is black. The channel with the red, normal input will later be connected to the red, positive terminal of your loud-speaker.

# 3 CONNECTTHE SINGLE-ENDED BRIDGING OUTPUT ADAPTER TO TWO SIDE-BY-SIDE BLACK OUTPUT TERMINALS

Connect one end of the Balanced Bridging Output Adapter to a black output terminal on one side of the amplifier, and then connect the other end to a black output terminal on the other side of the amplifier (The two connections should be side-by-side rather than one above the other) Make sure these connection are snug and secure.

# 4 CONNECTYOUR LOUDSPEAKER WIRE ACROSS TWO SIDE-BY-SIDE, RED OUTPUTTERM IN A LS

Please read the following carefully:

Connect the positive/+/red binding post of your loudspeaker to the red output terminal associated with the red (normal) side of the Input Adapter

Connect the negative/—/black binding post of your loudspeaker to the red output terminal on the other side of the amplifier, the one associated with the black (inverted) side of the Input Adapter.

Following this connection convention preserves the polarity of the signal sent to the loudspeaker In practice, the most important thing is to be consistent throughout the system, as inconsistency will result in out-of-phase loudspeakers. In turn, this results in unstable imaging and poor bass reproduction. (The effect is not dangerous, but neither is it subtle.)

# 5 CONNECTONE OUTPUT CHANNEL OF YOUR PREAMPLIFIER TO THE INPUT OF YOUR BRIDGED AMPLIFIER

The female RCA at the junction of the Single-Ended Bridging Input Adapter is now the *single* input to this *bridged* amplifier.

### 6 REPEAT AS NEEDED FOR OTHER CHANNELS

### 7 POWER UP YOUR AM PLIFIER

Plug the amplifier back into the AC mains; engage the power button, followed a few seconds later by pressing standby to turn on the amplifier

# Biamplification

In contrast to bridged operation (wherein two amplifier channels are "fooled" into behaving as a single, larger channel), biamplification makes use of two channels to drive different portions of a single loudspeaker. As with bridging, it offers a modular way of increasing the overall performance of your system (if your loudspeakers support biamplification).


Since each channel of the amplifier is delivering current into its load only over a limited range of frequencies (typically bass vs mids and treble), several forms of distortion may be reduced as compared to each channel handling the full range of musical information. For this reason, many loudspeaker companies are designing their products to include multiple speaker inputs (since using multiple amplifiers improves the performance of their products as well). Another common use of biamplification involves adding a subwoofer (along with an appropriate electronic crossover) to supplement and/or improve the deep bass performance of your system.

Always refer to the specific directions provided by your loudspeaker manufacturer prior to setting up a biamplified speaker system. Any instructions contained herein cannot be substituted for those that are specific to the loudspeaker in question. In general, however, biamping is done in one of two ways: active biamplification, or passive biamplification.

Active biamping refers to the presence of an "active" electronic crossover that divides the music into two (or sometimes more) bands of frequencies. These are then forwarded to separate power amplifiers, and sent on directly to the appropriate drivers in the speakers. The most common application of this approach is the use of a subwoofer crossover to separate the deep bass (below, say, 80 Hz) from the rest of the program material. It is then amplified separately and sent to a dedicated subwoofer designed to handle those extremely low frequencies.

Apart from adding a subwoofer, the next most common form of biamping (called passive biamplification) involves merely using a conventional "Y-adapter" (either balanced or single-ended) to provide a full range signal to two channels.

### Balanced Y-adapter



The outputs of these two channels are then connected to two sets of binding posts on each loudspeaker. The loudspeaker's internal crossover continues to divide the frequencies appropriately among the various drivers.

To facilitate biamping, all Proceed power amplifiers have the same voltage gain and input sensitivity. We even adjust for the difference between single-ended and balanced signal levels, should you have to mix the two. Because of this fact, you should not have to concern yourself with adjusting the relative volumes of the bass and treble sections of your loudspeakers—if they sounded good with a single amplifier, they should sound better when biamplified.

# Care & Maintenance

To remove dust from the cabinet of your amplifier, use a feather duster or a lint-free soft cloth. To remove dirt and fingerprints, we recommend isopropyl alcohol and a soft cloth. Dampen the cloth with alcohol first and then lightly clean the surface of the amplifier with the cloth. Do not use excessive amounts of alcohol that might drip off the cloth and into the amplifier



Caution!

At no time should liquid cleaners be applied directly to the amplifier, as direct application of liquids may result in damage to electronic components within the unit.

# **US and Canadian Warranty**

### 90-Day Limited Warranty

This Proceed® product is warranted to be free from defects in material and workmanship under normal use for a period of ninety (90) days from the date of purchase. *To extend the warranty of this Proceed product*, return the warranty registration card along with a copy of the original receipt of purchase to Madrigal Audio Laboratories, Inc., P. Q. Box 781, Middletown, CT 06457.

### Five Year Extended Warranty

The extended warranty for this Proceed product is five (5) years from the date of purchase. During the warranty period, any Proceed component exhibiting defects in materials and/or workmanship will be repaired or replaced, at our option, without charge for either parts or labor, at our factory. The warranty will not apply to any Proceed component that has been misused, abused or altered.

Any Proceed component not performing satisfactorily may be returned to the factory for evaluation. Return authorization must first be obtained by either calling or writing the factory prior to shipping the component. The factory will pay for return shipping charges only in the event that the component is found to be defective as mentioned above. There are other stipulations that may apply to shipping charges.

There is no other express warranty on this component. Neither this warranty nor any other warranty, express or implied, including any implied warranties of merchantability or fitness, shall extend beyond the warranty period. No responsibility is assumed for any incidental or consequential damages. Some states do not allow limitations on how long an implied warranty lasts and other states do not allow the exclusion or limitation of incidental or consequential damages, so that the above limitation or exclusion may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. **This warranty is applicable in the United States and Canada only.** Outside of the US and Canada, please contact your local, authorized Proceed distributor for warranty and service information.

# Obtaining Service

We take great pride in our dealers. Experience, dedication, and integrity make these professionals ideally suited to assist with our customers' service needs.

If your Proceed component must be serviced, please contact your dealer. Your dealer will then decide whether the problem can be remedied locally, or whether to contact Madrigal for further service information or parts, or to obtain a Return Authorization. The Madrigal Technical Services Department works closely with your dealer to solve your service needs expediently.



Important!

Return authorization <u>must</u> be obtained from Madrigal's Technical Services Department BEFORE a unit is shipped for service.

It is extremely important that information about a problem be explicit and complete. A specific, comprehensive description of the problem helps your dealer and the Madrigal Technical Services Department locate and repair the difficulty as quickly as possible.

A copy of the original bill of sale will serve to verify warranty status. Please include it with the unit when it is brought in for warranty service.



Warning!

All returned units must be properly packaged (preferably in their original packing material), and the proper return authorization numbers must be marked on the outer carton for identification. If the packaging to protect the unit is, in our opinion or that of our dealer, inadequate to protect the unit, we reserve the right to repackage it for return shipment at the owner's expense. Neither Madrigal nor your dealer can be responsible for shipping damage due to improper (that is, non-original) packaging.

Your dealer can order a new set of shipping materials for you if you need to ship your component and no longer have the original materials. There will be a charge for this service. We *strongly* recommend saving all packing materials in case you need to ship your unit some day.

# Specifications: HPA 3

The correlation between published specifications and performance is unreliable. A list of numbers reveals virtually nothing. All technical measurements must be subject to qualitative as well as quantitative interpretation. Measurements of the Proceed amplifier yield excellent results by any standards. However, only those specifications that apply to its actual operation are included here. All specifications are subject to change at any time, in order to improve the product

Rated power output: 250 w/ch rms @8 $\Omega$ , all channels driven, 20 Hz-20 kHz with no more than 0.1% THD 500 w/ch into  $4\Omega$ Frequency response: within 0.15 dB from 20 Hz to 20 kHz Signal to Noise ratio (main outputs): better than -80 dB (ref. 1 w) Input impedance:  $100k\Omega$  (balanced)  $11k\Omega$  (single-ended) Voltage gain: 23 dB (balanced) 29 dB (single-ended) Input sensitivity: 3.17 Vrms for full rated output (balanced) 1.586 Vrms for full rated output (single-ended) less than 125W in standby Power consumption: less than 200W when fully on and at idle less than 2500W maximum determined by the needs of country for which Mains voltage: the unit was manufactured; cannot be reset by dealer or user Overall dimensions: See "Dimensions" Shipping weight: 115 lbs. (52 kg) Connector Complement: two binding posts per channel one 3-pin XLR balanced input connector per channel one RCA input connector per channel two 1/8" mini-jacks for remote turn-on and loop-through two RJ-45 modular connectors for PHAST<sup>TM</sup> communications one IEC AC mains connector Output impedance: less than  $0.05\Omega$ , 20 Hz - 20 kHz


For more information, see your Proceed dealer, or contact:

### Madrigal Audio Laboratories, Inc.

P.O. Box 781
2081 South Main Street (Route 17)
Middletown, Connecticut 06457 USA
Telephone (860) 346-0896
EAX (860) 346-1540
Internet http://www.madrigal.com/

Madrigal provides an owner-transferable, five year extended warranty on all Proceed products within the U.S. and Canada ONLY. Warranty and service policies outside the U.S. and Canada are set by the local, authorized distributor and are applicable in the country of purchase ONLY. Madrigal products are designed to operate at set voltages appropriate for the country of sale and may be damaged if operated at the wrong voltage.


# Dimensions



# Rack Mounting

If you need or prefer to rack mount your amplifier, contact your Proceed dealer about the optional rack mount kit. This purpose-designed assembly provides the needed ventilation for the heatsink "chimneys" of the amplifier as well as the support required for this heavy component.

To use the rack mount kit, simply bolt the shelf securely to the rack, slide the amplifier into place, and then mount the provided trim ring around the faceplate of the amplifier (which will protrude from the rack by approximately one inch or 2.5 cm). The drawing below will help you visualize the assembly (the Proceed Five Channel Amplifier is illustrated below, but the assembly is the same for the HPA amplifiers).



The mounted amplifier and rack mount kit occupies 5 standard rack units of height

Installation Notes

# Installation Notes



Madrigal Audio Laboratories, Inc. 2081 South Main Greet, P.O. Box 781 Middletown, Connecticut 06457 USA

> Telephone: (860) 346-0896 Fax: (860) 346-1540 http://www.madrigal.com/



is a registered trademark of Madrigal Audio Laboratories, Inc. **H** a Harman International company